



And pop this one to, and loosen the two screws behind it.

Θ

m

x 1000 r/min

6

19

60

-40

20

-0

1 6

km/h

N

D

3

2

n

8

9

While carefully sliding the plastic "frame" out, organize the switch assys as shown here

6

* 1000 t/m

100

55521

8 78

ke/h

- 80

-40

20

10

P

A

ND

3

8

9

200 - 220-

250-

240-

11111

- And here.

ILIN UILEADED FUEL ONLY

This one has a very short cable :(

Pull the plastic panel out carefully, and your done :)