

## SVX 92MY for North America

	MAINTENANCE ITEM	MAINTENANCE INTERVAL (Number of months or km (miles) whichever occurs first)										REMARKS
		Months x 1,000 km x 1,000 miles	3 4.8 3	7.5 12 7.5	15 24 15	22.5 36 22.5	30 48 30	37.5 60 37.5	45 72 45	52.5 84 52.5	60 96 60	
1	Drive belt(s) [Except camshaft] (Inspect drive belt tension)					I					R	
2	Timing belt (Camshaft drive belt)					I*					R	
3	Engine oil		R	R	R	R	R	R	R	R	R	See NOTE 1
4	Engine oil filter		R	R	R	R	R	R	R	R	R	
5	Replace engine coolant and inspect cooling system, hoses and connections					P					P	
6	Replace fuel filter and inspect fuel system, line and connections					(P)					P	See NOTE 2, 6 & 7
7	Air filter elements					R					R	
8	Spark plugs										R	
9	Differential (Front & Rear) lubricants (Gear oil)					I						See NOTE 3
10	Automatic transmission fluid					I						See NOTE 4
11	Brake fluid					R					R	See NOTE 5
12	Disc brake pad and disc, Front and rear axle boots and axle shaft joints			I		I		I			I	See NOTE 6
13	Brake linings and drums (parking brake)					I					I	See NOTE 6
14	Inspect brake line and check operation of parking and service brake system			P		P		P			P	See NOTE 6
15	Steering and suspension			I		I		I			I	See NOTE 6
16	Front and rear wheel bearing lubricant										(I)	
17	Supplemental restraint system	Inspect every 10 years										

\* This maintenance operation is required for all states except California.

However, we do recommend that this operation be performed on California vehicles as well.

## NOTES

- 1) When the vehicle is used under severe driving conditions such as those mentioned below,\*\* the engine oil should be changed more often.
- 2) When the vehicle is used in extremely cold or hot weather areas, contamination of the filter may occur and filter replacement should be performed more often.
- 3) When the vehicle is frequently operated under severe driving conditions, replacement should be performed every 48,000 km (30,000 miles).
- 4) When the vehicle is frequently operated under severe driving conditions, replacement should be performed every 24,000 km (15,000 miles).
- 5) When the vehicle is used in high humidity areas or in mountainous areas, change the brake fluid every 24,000 km (15,000 miles) or 15 months, whichever occurs first.
- 6) When the vehicle is used under severe driving conditions such as those mentioned below,\*\* inspection should be performed every 12,000 km (7,500 miles) or 7.5 months, whichever occurs first.
- 7) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.

**\*\*Examples of severe driving conditions:**

- (1) Repeated short distance driving. (Items 3, 12 and 13 only)
- (2) Driving on rough and/or muddy roads. (Items 12, 13 and 15 only)
- (3) Driving in dusty conditions.
- (4) Driving in extremely cold weather. (Items 3 and 15 only)
- (5) Driving in areas where roads salts or other corrosive materials are used. (Items 6, 12, 13, 14 and 15 only)
- (6) Living in coastal areas. (Items 6, 12, 13, 14 and 15 only)